

SOUTHERN RAILWAY

मुख्यालय का कार्यालय/ Headquarters Office, परिवहन शाखा/Transportation Branch, चेन्नई /Chennai – 600 003.

सं/ No.T.157/Amendment to GR/2025

दिनांक /Date: 09.05.2025.

DRMs/ MAS, SA, PGT, TVC, MDU & TPJ

Correction Memo. No.05/2025 to GRS

1. Substitute the following for SR 9.12/2(A)(7):

(7) "After ensuring that the first train has arrived safely at the station ahead of the affected section, the Loco Pilots/Motorman of all subsequent trains may be permitted to run at their sectional speed duly proceeding with great caution from one kilometre before the Semi-Automatic/ Manual First Reception Stop Signal, subject to other speed restriction in force. The speed over facing points, if any, being restricted to 15 KMPH."

2. Replace the existing Forms T/D 912 & T/A 912 with Forms as enclosed:

[Ref: - Railway Board letter No.2024/TT-IV/12/10 dated 08.04.2025]

This has the approval of the Authorized Officer.

Please acknowledge receipt of the same and all concerned may please be notified.

Encl: Revised Forms T/D 912 & T/A 912

(एस. सुरेश S. Suresh) उप मुपरिप्र/नियम एवं संरक्षा **Dy. COM/Rules & Safety** /प्रमुपप्र/ PCOM

Copy to: -

Secv to GM- for the kind information of GM

AGM, PCSO, PCSTE, PCEE, PCME, PCE, CAO/CN/MS & ERS, CPM/RE, CSTE/Projects,

Principal/MDZTI/TPJ, Principal/DTTC/GOC, Principal/ZETTC/AVD &

Principal/SRCETC/TBM

PCOM/SWR, PCOM/SCR &PCOM /KRCL - for kind information.

Sr.DOMs/MAS, SA, PGT, TVC, TPJ & MDU - for information and action please.

Sr.DOMs/BZA,GTL,SBC & MYS.

SOUTHERN RAILWAY

Form No. T/D 912

Serial No.

AUTHORITY TO PROCEED FOR WORKING OF TRAINS
DURING PROLONGED SIGNAL FAILURE IN AUTOMATIC BLOCK SYSTEM
(Loco Pilot / Train Manager / Station Master's Record)

Station Date To			_hours				
The Motorman / Loco Pilot of Engine / Train /	Unit No		UP/	DOWN.			
<u>AUTHORIT</u>	Y TO PROCEE	<u>D</u>					
 All signals between	station	under his Pr	station ha	ive failed. ords)			
3. You are authorized to work your Engine / Transaction Automatic/Manual First Reception Stop Signature thereafter be guided by the aspect of the Seminstructions from the Station Master of the	gnal of i-Automatic / Ma	anual First R	eception Stop S	station and			
AUTHORITY TO PAS	S SIGNALS IN	'ON' POSITI	<u>ON</u>				
You are also authorized to pass							
Departure signals and all intervening Autom and station at "ON".							
 Starter/ Manual Stop Signal/ Gate Stop sign railway servant in uniform. You shall cautiously pass level crossing gates Here indicate the distinguishing num 	only after ensur	ring that the	gates are close	d.			
CAU	TION ORDER						
* Your train is the first train to pass over the Usignalling from station to restricted to 25 kmph when the view is subject to other speed restrictions.)		_ station. Spec	ed shall be			
* Your train is NOT the first train and is authorized to pass over the UP / DOWN* line from station to station with the Sectional speed subject to other speed restrictions. Proceed with great caution from km , that is one km before approaching Semi-Automatic / Manual first Reception Stop Signal.							
The speed over facing points, if any, being	restricted to 15	5 kmph.					
		*Strike out v	whichever is no	t applicable.			
							
I have understood the contents of this authority		Signature a	nd Stamp of Sta	ation Master			
Signature of Train Manager	Date:	Time	: hours _	mins			
Signature of Loco Pilot/ Motorman	Date:	Time:	:hours	_ mins			

SOUTHERN RAILWAY

Form No. T/A 912**

Serial No.____

AUTHORITY TO PASS AUTOMATIC/SEMI AUTOMATIC/ MANUAL STOP SIGNAL / GATE STOP SIGNALS

(Loco Pilot / Train Manager / Station Master's Record)

Station Date To		Time:	hours	mins			
The Motorman / Loco Pilot of Engine / Train / Un (a) Automatic Signalling has failed and you are, here							
station and		_ station.	In addition,	you are also			
authorized to pass Semi-Automatic / Manual Sto	p Signal / Gate	e Stop signa	als on being h	nand signalled			
past such signals by a railway servant in uniform, the hand signals being displayed except as							
provided for in clause 'b'.							
(b) When running in wrong line (i) you must ascertain those points of outlying sidings, where provided,							
are correctly set and locked and/or the level crossing gates Nos							
			ar	e closed and			
(ii) hand signals are displayed by the railway s before passing them.	ervant in unifo	orm at the p	ooints/level c	rossing gates			
Here indicate distinguishing Number of all signals to be thus passed							
<u>CAUTION ORDER</u>							
Your train is going to pass signal/s at ON, speed shall be restricted to <u>25</u> kmph when view is clear and <u>10</u> kmph when approaching or passing any portion of the line where the view ahead is not clear due to curve, obstruction, rain, fog subject to observance of other speed restriction in force.							
The speed over facing points, if any, being restr	icted to 15 km	nph.					
*Strike out whichever is not applicable.							
		Signature ar	nd Stamp of S	Station Master			
I have understood the contents of this authority							
Signature of Train Manager	_ Date:	Time:	hours	s mins			
Signature of Loco Pilot/Motorman	Date: _	Tim	ne:hour	s mins			

^{**} T/A 912 shall always be issued along with one of these forms –T/B 602,T/511 or T/F 602.

^{**} When T/A 912 is issued along with other forms most restrictive speed mentioned in given forms must be followed.